

SOUND SILENCER

LVT/UNIVERSAL SOUND CONTROL UNDERLAYMENT

APPROVED SUBSTRATES

Can be installed above dry and completely cured concrete, interior plywood, Gypcrete or poured and sealed gypsum underlay, cement backer units and properly prepared OSB.

FLOATING INSTALLATION

Underlay should be stored at room temperature for at least 24hrs pre installation.

Step 1:
Subfloor surface must be structurally sound, clean and dry before installation. Check for protruding nails and / or defects in the subfloor. Always be sure the moisture and alkalinity rates are within acceptable standards.

Step 2:
Start in a corner and begin installation of the underlayment. Unroll underlayment parallel to the wall in the opposite direction as you plan to install the flooring planks, moisture barrier side down.

Step 3:
Roll out next row in the same manner butting foam close to the first row. Do not overlap rubber pad.

Step 4:
Seal all open seams with aggressive adhesive 2" plastic tape.

Step 5:
Install flooring per manufacturer's instructions.

SOUND ABSORPTION

Luxury Vinyl Tiles & Planks
STC 63 dB | IIC 73 dB | DELTA 27 dB

Laminate & Wood Products
STC 63 dB | IIC 67 dB | DELTA 25 dB

LEED® POINT CATEGORIES

- 100% post-consumer recyclable
- Acoustical Properties - LEED® IEQp3
- Low Emitting Materials - LEED® EQ4.3
- Regional Priority - LEED® MRc5.1, 5.2

PROPERTIES	UNDERLAYMENT
GREEN APPROVAL	CRI GREEN LABEL PLUS CERTIFIED FOR OPTIMAL INDOOR AIR QUALITY
APPLICATIONS	RESIDENTIAL & COMMERCIAL
THICKNESS	1.8 MM
DENSITY	25/LB3
MOISTURE BARRIER	ON REQUEST
CONTENT	100% VIRGIN RUBBER
SUBSTRATES	NON-WOVEN
ROLL WIDTH	3 FT (36")
ROLL LENGTH	66.66 FT
ROLL WEIGHT	33 LBS
FULL ROLL	200 SF
COLOR	RED
WARRANTY	LIMITED LIFETIME WARRANTY

APPROVED FOR USE UNDER

Luxury Vinyl Tiles & Planks, Laminate, Engineered Wood, Hardwood

INSTALLATION METHODS

Float, Single Glue, Double Glue, Staple or Nail



SOUND SILENCER

LVT/UNIVERSAL SOUND CONTROL UNDERLAYMENT

FLOORING PRODUCTS: Luxury vinyl tiles and planks, laminate, engineered wood and hardwood

Floor Prep

Sub-floor must be level, clean and dry with no protruding nails or staples. Concrete sub-floor moisture emission rate may not exceed 3 lbs. / 1,000 sq. ft. / 24 hrs in accordance with ASTM F1869. If moisture emissions exceed this level an additional moisture barrier may be required.

ACCLIMATE UNDERLAYMENT FOR A MINIMUM OF 24 HRS. PRIOR TO INSTALLATION.

RELATIVE HUMIDITY MAY NOT EXCEED 65%.

Floating Installation

1. Roll out underlayment fabric side up and parallel to the wall, in the opposite direction the floor covering will be installed.
2. Trim the underlayment to fit the sub-floor, leaving a ¼" gap at each wall.
3. Roll out the next section of underlayment in the same manner making sure the seams are butted together but not overlapping, and close the seams using a 2" wide aggressive adhesive tape.
4. Install the floor covering according to the manufacturer's guidelines.

Nail-Down Installation

1. Roll out underlayment fabric side up and parallel to the wall in the opposite direction the floor covering will be installed.
2. Trim the underlayment to fit the sub-floor leaving a ¼" gap at each wall.
3. Roll out the next section of underlayment in the same manner making sure the seams are butted together but not overlapping and close the seams using a 2" wide aggressive adhesive tape.
4. Install the floor covering according to the manufacturer's guidelines.

BE SURE TO ADJUST THE AIR PRESSURE WHEN USING A NAIL GUN SO THAT THE NAIL/STAPLE IS FIRMLY SET BUT NOT FULLY COMPRESSING THE UNDERLAYMENT.

Double Glue Installation

Gluing underlayment to sub-floor

Premium flooring adhesives should be used. Proper adhesives can be obtained from a wide range of manufacturers. Prior to installation, contact the adhesive manufacturer to verify compatibility or refer to the approved adhesives list available at www.foamsolutionsinc.com

Be sure and follow the adhesive manufacturer's recommendation for trowel size, all site guidelines and installation instructions.

1. Roll out underlayment fabric side up and parallel to the wall in the opposite direction the floor covering will be installed.
2. Trim the underlayment to fit the sub-floor leaving a ¼" gap at each wall.
3. Roll out the next section of underlayment in the same manner making sure the seams are butted together but not overlapping
4. Begin to apply adhesive to the sub-floor by pulling back the cut to size underlayment. Be sure to use the recommended trowel size recommended by the adhesive manufacture. Allow adhesive to become tacky before setting the underlayment (DO NOT WET SET UNDERLAYMENT) and be careful not to trap bubbles.
5. Roll completed underlayment installation with a 35 lb. roller in both directions to ensure an adequate bond.
6. Repeat steps 3 & 4 for the entire installation.
7. Allow recommended adhesive cure time before walking, or placing anything, onto the installed underlayment.
8. Install the floor covering according to the manufacturer's installation instructions. Note: When installing vinyl flooring tiles or planks be sure to allow adhesive to become tacky to the touch before installation of flooring over underlayment. DO NOT WET SET FLOORING PRODUCTS OVER UNDERLAYMENT

Single Glue Installation

Floating Underlayment over Sub-Floor

1. Roll out underlayment fabric side up and parallel to the wall, in the opposite direction the floor covering will be installed.
2. Trim the underlayment to fit the sub-floor, leaving a ¼" gap at each wall.
3. Roll out the next section of underlayment in the same manner making sure the seams are butted together but not overlapping, and close the seams using a 2" wide aggressive adhesive tape .
4. Install the floor covering according to the manufacturer's installation instructions. Note: When installing vinyl flooring tiles or planks be sure to allow adhesive to become tacky to the touch before installation of flooring over underlayment. DO NOT WET SET FLOORING PRODUCTS OVER UNDERLAYMENT

DISCLAIMERS: IN SINGLE GLUE INSTALLATIONS (FLOATING THE UNDERLAYMENT AND GLUING FLOORING MATERIAL ON TOP) PLEASE NOTE THAT THE UNDERLAYMENT IS NOT DESIGNED TO COUNTERACT FLOORING MATERIAL MOVEMENT OR CHANGES IN WIDTH OR LENGTH DUE TO TEMPERATURE FLUCTUATIONS OUTSIDE THE SPECIFIED ACCEPTABLE RANGE OF THE FLOORING MANUFACTURERS. ANY CLAIMS RESULTING FROM CUPPING, PEAKING, WARPING OR OTHER DEFORMATION OF FLOORING PLANKS OR TILES WILL NOT BE APPROVED OR ACCEPTED.

DO NOT WET SET UNDERLAYMENT OR FLOORING MATERIALS INTO ADHESIVE. BE SURE TO ALLOW THE ADHESIVE TO PROPERLY FLASH AND BECOME TACKY TO THE TOUCH BEFORE APPLICATION OR FAILURES COULD RESULT SUCH AS SEPERATION OF THE PLANKS OR TILES, CUPPING, PEAKING OR OTHERWISE.

ONLY APPROVED AND TESTED ADHESIVES SHOULD BE USED.

Approved Adhesives For: Luxury vinyl tiles and planks

- MAPEI
 - ECO360
 - ECO373
 - G90
 - G21
- ROBERTS
 - 6300
- FRANKLIN
 - TITEBOND 670
 - TITEBOND 771-STEP
 - TITEBOND 811
- BOSTIK
 - BEST FLOORING ADHESIVE
 - EFA
 - GREENFORCE
 - GREEN FUSION
- STAUFF
 - D-737
 - D764
- TEC
 - 744 SOLID VINYL PLANK AND TILE ADHESIVE
 - 752 PREMIUM TRANSITIONAL VINYL ADHESIVE